
1949-53 Ford& Mercury Skivbromskit

Objektnr. 91032003

Få moderna bromsar på din 1949-1953 Ford med vår kompletta 11" skivbromssats

Detta kit är designat för att fungera med dina vanliga hjul (15" och större)
Har 11" tums ventilerade skivor, metriska bromsok, glidbultar, bromsslangar, krossbrickor, dammlock och alla tätningar, lager och hårdvara

Servicevänlig design säkerställer god körbarhet

Levereras med detaljerade instruktioner för att ge en enkel installation

1949 Ford Custom Tudor, Fordor Coupe & Convertible

1949 Ford Deluxe Tudor, Fordor Coupe & Convertible

1950 Ford Country Squire All

1950 Ford Crestline All

1950 Ford Crestliner All

1950 Ford Custom Tudor, Fordor Coupe & Convertible

1950 Ford Deluxe Tudor, Fordor Coupe & Convertible

1951 Ford Country Squire All

1951 Ford Crestline All

1951 Ford Custom Tudor, Fordor Coupe & Convertible

1951 Ford Deluxe Tudor, Fordor Coupe & Convertible

1951 Ford Victoria All

1952 Ford Country Squire All

1952 Ford Crestline Tudor, Fordor & Coupe

1952 Ford Crestline Victoria All

1952 Ford Mainline Tudor, Fordor & Coupe

1952 Ford Sunliner All

1952 Mercury Custom All

1952 Mercury Monterey All

1953 Ford Crestline Tudor, Fordor Coupe, Convertible & Wagon

1953 Ford Customline Tudor, Fordor Coupe, Convertible & Wagon

1953 Ford Mainline Tudor, Fordor Coupe, Convertible & Wagon



MODERN STOPPING POWER

Gain modern stopping power on your 1949-53 Ford with our complete 11" disc brake kit.

GOOD DRIVABILITY

Serviceable design ensures good drivability and peace-of-mind when centered.

DESIGNED FOR STOCK WHEELS

This kit is designed to work with your stock wheels (15" and larger).

EVERYTHING YOU NEED

Features 11" cast iron rotors, loaded metric calipers, slide bolts, brake hoses, crush washers, dust caps, and all seals, bearings, & hardware.

1953 Ford Victoria All

1953 Mercury Custom All

1953 Mercury Monterey All

Se denna produkt på vår hemsida:

<http://www.kvarnbergproducts.se/products/view/1949-53-ford-mercury-skivbromskit>
